

TO ASSEMBLE THE LATERAL CONVEYOR YOU NEED TO:

1. OPEN THE LATERAL CONVEYOR – PICTURE 1
2. FIT THE OPEN CONVEYOR BY TURNING IT ON THE DISC (THIS STEP COULD BE DIFFICULT IF THE MACHINE HAS THE PROTECTION GRATE CEE)- PICTURE 2
3. CLOSE THE CONVEYOR- PICTURE 3
4. FIX THE CONVEYOR TO THE FRAME USING THE BRACKETS WITH THE APPROPRIATE NUTS AND BOLTS- PICTURES 4/5/6/7/8
5. ADJUST THE CONVEYOR OPENING BY USING SCREWS AND KNOBS – PICTURE 9



PICTURE 1



PICTURE 2



PICTURE 3



PICTURE 4



PICTURE 5



PICTURE 6



PICTURE 7



PICTURE 8



IMMAGINE 9