



Honda GX160

Ref #	Frederick #	OEM #	ASC #	Description
1	31-052	28400-ZH8-013ZA	57148	Starter assy.,NEW STYLE
2	43-425	28442-ZH8-003		Starter spring
3	31-023	28420-ZH8-013		Starter pulley
4	31-088	28443-ZH8-003		Starter pawl spring
5	31-025	28422-ZH8-013		Starter pawl
6	31-027	28433-ZH8-003		Starter pawl retainer
7	31-028	90003-ZH8-003		Starter center screw
8	33-013	36100-ZE1-015	57157	Switch,on/off
9		19610-ZE1-000ZA		Blower housing
10	30-346	17211-ZE1-000	71827	Air filter
11	31-026	28451-ZH8-003		Starter cup
12	07-393	16955-ZE1-000		Fuel tank joint
13	55-126	17620-ZE2-W00	57170	Fuel cap, plastic
14	07-118	17672-ZE2-W01		Fuel strainer
15	07-600	17510-ZE1-020ZA	66874	Fuel tank
16	07-060	95001-45200-40S		Fuel line
17		34150-ZH7-003		Diode assy
18		96100-62050-00/91001-ZF1-003		Ball bearing,crankshaft
19	33-541	15510-ZE1-033		Oil level switch
20	50-450	11381-ZH8-801		Gasket, sump cover
21	49-196	15600-ZE1-003		Oil cap and indicator
22	49-208	91202-883-00	57166	Oil seal PTO
23	50-451	15600-ZE1-003	66816	Oil cap
24	36-141	13200-ZE1-010		Connecting rod (std)
25	36-243	13101-ZF7-010		Piston (std)
26	36-043	13010-ZF1-023	57160	Ring set (std)
27		19630-ZH8-000		Shield, cylinder lower
28	50-425	18381-ZH6-800		Gasket, muffler
29	35-041	18320-ZF1-H01		Muffler shield
30	35-038	18310-ZF1-000	61881	Muffler assy.
31		12310-ZE1-020		Rocker cover
32	50-432	12391-ZE1-000		Gasket, rocker cover
33	49-183	16212-ZH8-800		Gasket, carb insulator
34	49-190	16221-ZH8-801		Gasket, carb
35	49-914	16610-ZE1-000		Lever, choke
36	49-185	16220-ZE1-020		Gasket, air cleaner
37	33-348	30500-ZE1-033	57158	Ignition coil
38	36-521	14711-ZF1-000		Valve, intake
39	36-522	14721-ZF1-000		Valve, exhaust
40	50-556	12251-ZF1-000		Gasket, cylinder head
41	36-530			Long head assy.
42	50-638	16100-ZH8-W50		Carb assy.
43	49-208	91202-883-005	57166	Oil seal MAG

*** NON-Stocked but Previously Special Ordered Item**