



## 2 WHEEL RIGHT HAY RAKE ASSEMBLY



2 Wheel Right Hay Rake Assembly Part List

Part No	P.Name	Pieces
1	Frame	1
2	Assembly Rake	2
3	Pin	1
4	Pin	1
5	R pin	2
6	Lock	1
7	spindle	1



**Note:** Using an overhead hoist or fork lift,carefully tip the assembly in the approximate position it should be in when installed on the tractor and high enough off the ground to install the wheels.Install the wheels on the hubs using the capscrews,lockwasher and nuts the position of the teeth is determined by the direction of operation.