




## Caroni - Rotary Tiller - Complete Unit - FL800

(Circled Numbers Reference Chart Below Diagram)



Ref. #	Caroni Part #	QTY	ASC #	Descrip.
1	FL05800	1	30914	Gear Wheel
3	1078	9	47379	Screw 10x35mm
5	FL07400	1	33067	Special Screw
7	FL11900	1	40782	Gasket
9	FL07210	1	33068	Chain Stretcher
11	BL01400	2	41884	Washer
13	FL06910	1		Shield Left
15	FL12700	2	43370	Pin
17	1227	23	47394	Washer
19	FL012900	2	47512	Bush

Ref. #	Caroni Part #	QTY	ASC #	Descrip.
2	1099	19	47384	Screw
4	1104	1	41885	Nut
6	1098	24	47382	Screw
8	FL06000	1	40781	Side Housing
10	BL01300	2	41887	Nut
12	FL06100	1	30915	Gear Wheel
14	1611	4	43372	Linch Pin
16	1091	23	56167	Nut
18	FL12800	1	47511	Support Right
	FL06600	1	47497	Support Left
20	FL06700	2	47498	Coupling


21	1944	4	47442	Screw	22	1225	41	47391	Washer
23	1080	17	56107	Nut	24	FL12400	1	40783	Hitch Frame
25	1610	1	56233	Spring Clip	26	FL13000	1	36963	Top Link Pin
27	FL04720	1	56108	Frame 80	28	BL07200	1	43425	Gasket
29	FL00500	1	56111	Transmission Tube 80-90	30	FL13100			Shim
31	FL05500	1	52492	Transmission Shaft	32	FL05400	1	47495	Transmission Shaft 100-120
						1807	2	47436	Screw
33	1236	2	47399	Washer	34	59006410	1	56113	Stiffening Plate
35	59007300	1	47488	Gaurd	36	BL06900	1	52494	Gasket
37	FL13200	1	30913	Gearbox	38	1673	1	47249	Plug
39	FL04210	1	56221	Shield Right	40	1543	2		Spring Dowl
41	FL07900	1	56116	Axle 80	42	BL05700	1	40785	Pinion
43	1061	1	52493	Bearing	44	1210	1	41869	Oil Seal
45	1113	1	35369	Bearing	46	1373	1	30910	Chain
47	1357	1	43700	Nut	48	FL04300	2	47494	Adjusting Bar
49	1149	1	43698	Plug	50	1213	1	43699	Washer
51	FL03700	1	30911	Skid Left	52	1088	2	47071	Screw
53	1540	1	43701	Circlip	54	1115	1	41745	Bearing
55	1932	1	41746	Oil Seal	56	BL07300	1	42211	Gasket
57	FL01520	1	43702	Support Left	58	BL01900	1	43704	Spacer
59	FL01300	1	47075	Deflector	60	FL05100	1		Rotor 80
61	1105	*	56121	Nut	62	1205	*	56122	Washer
63	FL05800	1		Blade Right Hand	64	FL05700	1		Blade Left Hand
65	FL07300		53390	Chain	66	FL03600		56222	Pin
67	1558			Split Pin	68	1632	2	58286	Screw (7/16" x 1-1/2" Grade #5 Bolt
69	FL01200	1	43705	Deflector	70	FL01400	1	43706	Support Right
71	FL07500	1	52473	Hood 80	72	1064	1	42375	Bearing
73	1240	1	31420	Circlip	74	1028	1	31427	Circlip
75	1220	6	31439	Self Locking Nut	76	FL18400	1	56123	Rotor 80
77	FL17400	9	101402	Blade Right Hand - also 28543	78	FL04110	1	30912	Skid Right
	FL17500	9	101403	Blade Left Hand - also 28544					



**Caroni - Rotary Tiller - Transmission Boxes - FL800, FL1200 & FL1400**


(Circled Numbers Reference Chart Below Diagram)

**FL SCATOLA DI TRASMISSIONE - TRANSMISSION BOX  
TRANSMISSION COMPLET - GETRIEBE KOMPLETT**



Ref. #	Caroni Part #	QTY	ASC #	Descrip.
1	BL0300	1		Pinion
3	1213	1	43699	Washer
5	1240	1	31420	Circlip
7	1799		32855	Washer
	1216			Washer
	1215			Washer
9	FL01600	1	56126	Box
11	1067	1	47376	Circlip
13	1638	1	41527	PTO Shaft
	1853	1	45905	PTO Shaft with Clutch

Ref. #	Caroni Part #	QTY	ASC #	Descrip.
2	1149	1	43698	Oil Drain Plug
4	1209	1	47389	Oil Seal
6	1538	1	47420	Washer
8	1579	1	30896	Bearing
10	1065	1	42692	Bearing
12	FL06200		47496	Cover



# FL

RIF.	CODE	QTY	TYPE	DESCRIPTION	RIF.	CODE	QTY	TYPE	DESCRIPTION	RIF.	CODE	QTY	TYPE	DESCRIPTION
1	FL05800	1	ALL FL	GEAR WHEEL	43	1061	1	ALL FL	BEARING	16	FL120M			
2	1099	19	ALL FL	SCREW	44	1210	1	ALL FL	OIL SEAL	16	FL130M			
3	1078	9	ALL FL	SCREW	45	1113	1	ALL FL	BEARING	18	FL140M			
4	1104	1	ALL FL	NUT	46	1373	1	ALL FL	CHAIN	65	FL07300	1	ALL FL	CHAIN
5	FL07400	11	ALL FL	SPECIAL SCREW	47	1357	1	ALL FL	NUT	66	FL03600	1	ALL FL	PIN
6	1098	24	ALL FL	SCREW	48	FL04300	2	ALL FL	ADJUSTING BAR	67	1556	1	ALL FL	SPLIT PIN
7	FL11900	1	ALL FL	GASKET	49	1149	1	ALL FL	PLUG	68	1632	20	FL80M	SCREW
8	FL06000	1	ALL FL	SIDE HOUSING	50	1213	1	ALL FL	WASHER	24	FL90M			
9	FL07210	1	ALL FL	CHAIN STRETCHER	51	FL03700	1	ALL FL	SKID LEFT	24	FL100M			
10	BL01300	2	ALL FL	NUT	52	1088	2	ALL FL	SCREW	28	FL110M			
11	BL01400	2	ALL FL	WASHER	53	1540	1	ALL FL	CIRCLIP	32	FL120M			
12	FL06100	1	ALL FL	GEAR WHEEL	54	1115	1	ALL FL	BEARING	32	FL130M			
13	FL05910	1	ALL FL	SHIELD LEFT	55	1932	1	ALL FL	OIL SEAL	36	FL140M			
14	1611	4	ALL FL	LINCH PIN	56	BL07300	1	ALL FL	GASKET	36	FL80A			
15	FL12700	2	ALL FL	PIN	57	FL01520	1	ALL FL	SUPPORT LEFT	48	FL90A			
16	1091	23	ALL FL	NUT	58	BL01900	1	ALL FL	SPACER	48	FL100A			
17	1227	23	ALL FL	WASHER	59	FL01300	1	ALL FL	DEFLECTOR	48	FL110A			
18	FL12800	1	ALL FL	SUPPORTO RIGHT	60	FL05100	1	FL80M	ROTOR	60	FL120A			
19	FL06600	1	ALL FL	SUPPORT LEFT	60	FL05000	1	FL90M	ROTOR	60	FL130A			
20	FL012900	2	ALL FL	BUSH	60	FL04900	1	FL100M	ROTOR	72	FL140A			
21	FL06700	2	ALL FL	COULING	60	FL04800	1	FL110M	ROTOR	69	FL01200	1	ALL FL	DEFLECTOR
22	1944	4	ALL FL	SCREW	60	FL13800	1	FL120M	ROTOR	70	FL01400	1	ALL FL	SUPPORT RIGHT
23	1225	41	ALL FL	WASHER	60	FL03200	1	FL130M	ROTOR	71	FL07500	1	FL80	HOOD
24	1080	17	ALL FL	NUT	60	FL17100	1	FL140M	ROTOR	71	FL07600	1	FL90	HOOD
25	FL12400	1	ALL FL	HITCH FRAME	61	1105	20	FL80M	NUT	71	FL07700	1	FL100	HOOD
26	FL13000	1	ALL FL	SPRING CLIP	24	FL90M				FL07800	1	FL110	HOOD	
27	FL04720	1	FL80	FRAME	24	FL100M				FL13910	1	FL120	HOOD	
28	FL04620	1	FL90	FRAME	28	FL110M				FL02410	1	FL130	HOOD	
29	FL04520	1	FL100	FRAME	32	FL120M				FL16610	1	FL140	HOOD	
30	FL04420	1	FL110	FRAME	32	FL130M				72	1064	1	ALL FL	BEARING
31	FL13710	1	FL120	FRAME	36	FL140M				73	1240	1	ALL FL	CIRCLIP
32	FL01720	1	FL130	FRAME	36	FL80A				74	1026	1	ALL FL	CIRCLIP
33	FL16820	1	FL140	FRAME	48	FL90A				75	1220	6	ALL FL	SELF LOOKING NUT
34	BL07200	1	ALL FL	GASKET	48	FL100A				76	FL18400	1	FL80A	ROTOR
35	FL00500	1	FL80-FL90	TRANSMISSION TUBE	48	FL110A				FL18500	1	FL90A	ROTOR	
36	FL05200	1	FL100-FL110	TRANSMISSION TUBE	48	FL120A				FL18600	1	FL100A	ROTOR	
37	BL00600	1	FL130	TRANSMISSION TUBE	60	FL130A				FL18700	1	FL110A	ROTOR	
38	FL16200	1	FL140	TRANSMISSION TUBE	72	FL140A				FL18800	1	FL120A	ROTOR	
39	FL13100	1	ALL FL	SHM	62	1205	20	FL80M	WASHER	FL18900	1	FL130A	ROTOR	
40	FL05500	1	FL90-FL90	TRANSMISSION SHAFT	24	FL90M				FL19000	1	FL140A	ROTOR	
41	FL05400	1	FL100-FL100	TRANSMISSION SHAFT	24	FL100M				77	FL17400	9	FL80A	BLADE RIGHT HAND
42	FL14400	1	FL140	TRANSMISSION SHAFT	28	FL110M				12	FL90A			BLADE RIGHT HAND
43	1807	2	ALL FL	SCREW	32	FL120M				12	FL100A			BLADE RIGHT HAND
44	1236	2	ALL FL	WASHER	32	FL130M				12	FL110A			BLADE RIGHT HAND
45	FL06300	1	ALL FL	STIFFENING PLATE	36	FL140M				15	FL120A			BLADE RIGHT HAND
46	59007300	1	ALL FL	GUARD	36	FL80A				15	FL130A			BLADE RIGHT HAND
47	BL06900	1	ALL FL	GASKET	48	FL90A				18	FL140A			BLADE RIGHT HAND
48	FL13200	1	ALL FL	COMPLETE PTO DRIVE BOX	48	FL100A				9	FL80A			BLADE LEFT HAND
49	1673	1	ALL FL	PLUG	48	FL110A				12	FL90A			BLADE LEFT HAND
50	FL04210	1	ALL FL	SHIELD RIGHT	60	FL120A				12	FL100A			BLADE LEFT HAND
51	1543	2	ALL FL	SPRING DOWEL	60	FL130A				12	FL110A			BLADE LEFT HAND
52	FL07900	1	FL80	AXLE	72	FL140A				15	FL120A			BLADE LEFT HAND
53	FL08000	1	FL90	AXLE	10	FL80M				15	FL130A			BLADE LEFT HAND
54	FL08100	1	FL100	AXLE	12	FL90M				18	FL140A			BLADE LEFT HAND
55	FL08200	1	FL110	AXLE	12	FL100M				63	FL05600	10	FL80M	BLADE RIGHT HAND
56	FL14000	1	FL120	AXLE	14	FL110M				12	FL100M			
57	FL08300	1	FL130	AXLE	16	FL120M				14	FL130M			
58	FL16500	1	FL140	AXLE	16	FL130M				18	FL140M			
59	BL05700	1	ALL FL	BEVEL GEAR BOX	64	FL05700	10	FL90M	BLADE LEFT HAND	10	FL80M			
										12	FL100M			
										12	FL110M			
										12	FL120M			
										12	FL130M			
										12	FL140M			
										14	FL110M			