




W.L. Hamilton Co., 325 Cherry Street, P.O. Box 766, Marshall, Michigan 49068
 (616) 781-0649 • FAX (616) 781-6963
 PRINTED IN U.S.A.

ITEM	DESCRIPTION	PART NO.	ITEM	DESCRIPTION	PART NO.
1.	Inake Casting, %7 FGH11	100-001-02	19.	Latch	100-003-02
2.	Ferrule Washer	1001-002-02	20.	Packing Nut	1000-002-02
3.	Handle	100-051-89	21.	Packing Ring	1000-051-07
4.	Retaining Nut	1001-003-01	22.	Hose Gasket	1000-055-49
5.	Handle Locknut	1001-004-02	23.	Worm	1005-016-02
6.	Lower Valve Rod	1107-004-02	24.	Worm Nut	1005-058-02
7.	Latch Pin (2)	1100-054-05	25.	Upper Valve Rod	1005-010-02
8.	O-Ring	1100-053-09	26.	Barrel	1000-011-02
9.	Valve Stem	1100-008-03	27.	Valve Rod Guide	1005-014-02
10.	Trigger Pin	1100-052-05	28.	Nozzle Head	1005-008-02
11.	Valve Washer	1100-011-02	29.	Disc Gasket	1005-054-11
12.	Poly Valve	1100-058-11	30.	Orifice Disc	1005-004-32
13.	Valve Holder	1100-010-02	31.	Cap	1005-003-02
14.	"O" Ring	6702-059-09	32.	Rd. Head Screw	1005-057-02
15.	Compression Spring	1100-056-03	33.	Swirl Baffle	1005-006-02
16.	Valve Cap	1100-009-02	34.	Baffle Washer	1005-005-02
17.	Trigger	1100-002-02	35.	Shut-off Valve	1005-056-11
18.	Trigger Spring	1100-055-03	36.	Valve Holder	1005-007-02

PARTS LIST



MODEL NO. 1107-02 ALUM
 TRIGGER SPRAY GUN %7 FGH11 INLET

Item # 119388

7-30-04