


# 20 TON HYDRAULIC FLOOR PRESS



Parts No.	Description	Q'ty
1	Ram	1
2	Hex Bolt M8X35	6
3	Lock Washer Ø8	22
4	Upper Plate	2
5	Crossbeam	1
6	Hex Bolt M16X30	8
7	Hex Nut M16	8
8	Lock Washer Ø16	8
9	Under Plate	1
10	Pad Plate	2
11	Press Platform	1
12	Support Rod	2
13	Post	2
14	Hex Bolt M8X25	16
15	Hex Nut M8	16
16	Support	4
17	Angle Steel Feet	2
18	Spreader Weldment	1
19	Hex Bolt M10X16	3
20	Lock Washer Ø10	3
21	Pump Base	1
22	Pump	1
23	Pressure Guage	1

## A NOTE ON SAFETY

We've done all we can to assure this press offers the utmost in safety, but you have to do your part no amount of warning take the place of your good judgment, so make sure it's the first thing you bring to any job.

Beyond that there are some obvious tips:

- Steel and other materials can shatter, so always use protective eyewear that complies with the appropriate ANSI code.
- If you detect anything that may indicate imminent structural failure stop using the press immediately and inspect it thoroughly
- Bolt the press to the floor if it is to be used on bulky or unstable items.
- Do not use press to compress spring or any other item that could disengage and cause a potential hazard.