


Carrying strap	100cm x 3.5cm x 2
Tank capacity	12L / 16L / 20L

Parts diagram



List

Carrying strap hook
Rocker bar fastener
Washer
Carrying strap fixer
Pump
Seal ball
Seal valve
Seal ball
Cup ring
Carrying strap
Rocker bar
Air chamber
Tank
Felt seal
Rocker bar grip
Pressure lid of air chamber
Filter screen of tank
Sealing washer
Tank lid
Rocker bar fixer
Split pin

Parts List

1	Ring, rocker bar fixer
2	Connecting rod
3	Guide bushing
4	Split pin
5	Base
6	Washer
7	Nut
8	Washer
9	Screw
10	Strap buckle
11	Nozzle assy.
12	Washer
13	Wand
14	Switch component
15	Screw for switch
16	Wand nut
16-1	Locking sleeve
16-2	O-ring
17	Seal insert
18	Hose nut
19	Hose
20	Carrying strap fixer